

SPECIAL *Event* RENTALS

JBL Speaker Instruction Sheet

Equipment Included:

- JBL SPEAKER
- POWER CORD PLUG-IN FOR JBL SPEAKER
- SPEAKER STAND
- SPEAKER STAND BAG
- 15' EXTENSION PLUG FOR HAND HELD / LAPEL MICROPHONES

Instructions for Set-Up

1. Remove speaker from bag and make sure that it's upright; the control knobs should be in the upper right quadrant.
2. To assemble speaker stand, loosen knob and push down until stand is fully extended then tighten knots until snug.
3. To raise the height of the speaker loosen knob, lift up on top of pole then put lock pin through holes and tighten knob.
4. When placing speaker on stand ensure that the top of the speaker stand is fitted into the hole on the base of the speaker.
5. Plug power cord into speaker's upper left quadrant.

Edmonton

780-435-2211
6010-99 Street

Red Deer

403-347-7733
5929-48 Ave

Calgary

403-235-2211
2312-52 Ave

Banff

403-762-2227
150 Eagle Crescent