

# SPECIAL *Event* RENTALS


## ITEMS REQUIRED



STEAM TABLE



WATER PANS



## HOW TO OPERATE STEAM TABLE

1. Pour water in the removable water pans provided with the steam table. **NOTICE:** Do not pour water on the heating element.
2. Place food in insert pans that rest above the water pans. Food insert pans are rented separately.
3. Adjust control knobs to desired temperature.

## ELECTRICAL REQUIREMENTS



### DANGER

- Two 15 amp power outlets (110/115 Volts) on two separate breakers are required to fully operate. Plugging both power cords into outlets on the same breaker will result in power failure.
- Do not pour water on the heating elements. Failure to do so could result in serious injury, or death.
- Always unplug the equipment before cleaning or servicing.

## BEFORE RETURNING

- A \$37.50 cleaning charge will apply to each steam table if units are not returned in the same condition they were received.
- To avoid cleaning charges, empty water pans and remove food residue. Wipe down all interior and exterior surface areas clean.